



Aurega[®] Gold solution 9000

Easily dosable with exact gold content

This gold solution was developed specially for electroplating industry and is used for gold addition in sulfite gold alloy bathes. Because it is in form of a solution, simple and precise dosing is possible. The solution is used for bath make up as well as for Replenishment.



Properties and benefits

- Exact produced and checked gold content
- Easily dosable

Application area

- Aurega[®] blend Pd 9000

Aurega Gold solution 9000_E

our know-how
is your success

iwgplating.com





Technical Data

	Specification
Appearance	Clear, colourless solution
Turbidity	None
Gold content	100,0 ± 0,3 g/l
pH-Value	8,5 – 9,5
Sulfite	Min. 50 g/l

Product available

1162400 Aurega® Gold solution 9000

Statement

The precious metals which we utilise within the framework of our business activities have been sourced from legitimate origins and as such have not directly or indirectly financed armed conflict

FOR ANY FURTHER INFORMATION WE WILL BE PLEASED TO BE AT YOUR DISPOSAL
PERSONALLY UNDER+ 43 (0)2287 71073 OR OFFICE@IWGPLATING.COM.

03/2023

This information sheet supersedes and replaces any previous version of this information sheet.

This information shall be followed by every treatment, application, use and handling of our products and chemicals for your own safety. The information, directions for use, instructions and notices set forth herein with developed according to our best knowledge and belief. We do not assume liability for improper treatment, handling or use of our products and in particular of the chemicals and for the violation of this information

IWG Ing. W. Garhöfer Ges.m.b.H

Sonnenblumenweg 1
A-2282 Markgrafneusiedl
+ 43 (0)2287 71073
office@iwgplating.com

